
OTAC-E51 Adaptador para Computadora Portatil 19V/4.74AH C



Compatibilidades

ACER: Acer Note 367D, Acer Note 367T, Acer Note 390, Acer Note 390A, Acer Note 391, Acer Note 392, Acer Note 393, Acer Note 394, Acer Note 395, Anywhere 1100LX, Anywhere 1120LX, Aspire 1300 Series, Aspire 1310 Series, Aspire 1350, Aspire 5600, Aspire 5600 AWLMi, Aspire 5601WLMi, Aspire 5602WLMi, Aspire 5620, Aspire 5621AWLMi, Aspire 5622WLMi, Extensa 365, Extensa 366D, Extensa 367D, Extensa 368D, Extensa 390, Extensa 390C, Extensa 390CX, Extensa 393, Extensa 900, Extensa ESS3-391T, Ferrari 3000, Ferrari 3000LMi, Ferrari 3200, Ferrari 3400LMi, Ferrari 4000, TravelMate 240, TravelMate 242FX, TravelMate 244LCi, TravelMate 244LC-XPP, TravelMate 250, TravelMate 250PE, TravelMate 252ELC, TravelMate 252ELCi, TravelMate 254ELCi, TravelMate 4404. ASUS: A3000N, A9, A9C, A9R, A9RP, A9Rt, A9T, A9W, B80A, F3Q, F50GX, F50S, F50SV, F80S, F83T, G2p, G2s, G60, G60JX, K40C, K40IN, K40IP, K42, K42F, K42J, K50I, K50IJ-BBZ5, K50IJ-BNC5, K50IJ-RX05, K50IN-RBCBR05, K50I-RBBGR05, K52, K52DR-BIN6, K52F, K52F-BBR5, K52F-BBR9, K52F-BIN6, K52N-BGR5, K52N-BIN6, K60i, K60IJ, K60IJ-RBLX05, K60I-RBBBR05, K70, K70IJ, K72F, M51A, N10E, N10J, N10JB, N10JH, N50Vn, N51VF, N61, N80Vc, N80Vn, P30A, P30A, P30A, R1E, U30, U43, U43F, U43F-BBA5, U43F-BBA6, U43F-BBA7, U43JC, U43JC-1A, U43JC-BBA6, U50, U50F, U50F-RBBAG05, U52, U52F-BBG6, U52F-BBL5, U52F-BBL9, U52JC-BBG6, U80, UL30, UL30A-X5, UL50, UL80, UL80J, UL80J-BBK5, UL80VT-A1, UX50, UX50V, UX50V-A1, UX50VRF-RX05, X83Vb, X83VB-X2, X83Vm. COMPAQ: Armada 2940, Business Notebook NX9000, Business Notebook NX9010, Business Notebook NX9030, Evo N105, Evo N115, Evo N160, Evo N180, Presario 1000, Presario 1010, Presario 1020, Presario 1030, Presario 1040, Presario 1050, Presario 1060, Presario 1065, Presario 1070, Presario 1075, Presario 1080, Presario 1081, Presario 1090, Presario 1090ES, Presario 1200, Presario 1200T, Presario 1200US, Presario 1200XL, Presario 1200XL101, Presario 1200XL102, Presario 1200XL103, Presario 1200XL104, Presario 1200XL105, Presario 1200XL106, Presario 1200XL109, Presario 1200XL110, Presario 1200XL111, Presario 1200XL118, Presario 1200XL119, Presario 1200XL125, Presario 1200XL126, Presario 1200XL127, Presario 1200XL3, Presario 1200XL300, Presario 1200XL325, Presario 1200XL401, Presario 1200XL404, Presario 1200XL406, Presario 1200XL408, Presario 1200XL409, Presario 1200XL420, Presario 1200XL423, Presario 1200XL500, Presario 1200XL505, Presario 1200XL510, Presario 1200XL515, Presario 1200XL526, Presario 1201AP, Presario 1201Z, Presario 1207, Presario 1210, Presario 1214, Presario 1214SR, Presario 1215, Presario 1216, Presario 1220, Presario 1221, Presario 1230, Presario 1232, Presario 1234, Presario 1235, Presario 1236, Presario 1237, Presario 1240, Presario 1242, Presario 1244, Presario 1245, Presario 1246, Presario 1247, Presario 1250, Presario 1255, Presario 1256, Presario 1260,

Presario 1262, Presario 1266, Presario 1267, Presario 1270, Presario 1272, Presario 1273, Presario 1274, Presario 1275, Presario 1277, Presario 1278, Presario 1279, Presario 1280, Presario 12XL, Presario 12XL series, Presario 12XL115, Presario 12XL125, Presario 12XL300, Presario 12XL310, Presario 12XL325, Presario 12XL326, Presario 12XL327, Presario 12XL4, Presario 12XL400, Presario 12XL401, Presario 12XL405, Presario 12XL410, Presario 12XL420, Presario 12XL426, Presario 12XL427, Presario 12XL430, Presario 12XL500, Presario 12XL505, Presario 12XL510, Presario 1400, Presario 1400 series, Presario 1400T, Presario 1456, Presario 14XL, Presario 14XL240, Presario 14XL245, Presario 14XL340, Presario 14XL345, Presario 1600, Presario 1600XL145, Presario 1610, Presario 1611, Presario 1615, Presario 1620, Presario 1621, Presario 1622, Presario 1625, Presario 1626, Presario 1630, Presario 1635, Presario 1640, Presario 1650, Presario 1655, Presario 1665, Presario 1670, Presario 1672, Presario 1675, Presario 1680, Presario 1681, Presario 1682, Presario 1685, Presario 1687, Presario 1688, Presario 1690, Presario 1692, Presario 1693, Presario 1694, Presario 1700, Presario 1700T, Presario 1700XL573, Presario 1710, Presario 1710LA, Presario 1710SB, Presario 1710TW, Presario 1714EA, Presario 1720US, Presario 17XL, Presario 17XL265, Presario 17XL275, Presario 17XL360, Presario 17XL362, Presario 17XL365, Presario 17XL375, Presario 17XL460, Presario 17XL465, Presario 17XL475, Presario 17XL570, Presario 1800, Presario 1800T, Presario 1800T-800, Presario 1800T-850, Presario 1800XL, Presario 1800XL190, Presario 1800XL280, Presario 1800XL380, Presario 1800XL390, Presario 1800XL481, Presario 1805, Presario 1810, Presario 1825, Presario 1827, Presario 1830, Presario 18XL, Presario 18XL280, Presario 18XL380, Presario 18XL390, Presario 18XL580, Presario 18XL590, Presario 2100, Presario 2100 Series, Presario 2100AP, Presario 2100CA, Presario 2100LA, Presario 2100US, Presario 2101AP, Presario 2101US, Presario 2102AP, Presario 2102EA, Presario 2102US, Presario 2103AP, Presario 2103EA, Presario 2104AP, Presario 2104US, Presario 2105AP, Presario 2105CA, Presario 2105EA, Presario 2105LA, Presario 2105US, Presario 2106AP, Presario 2106EA, Presario 2106US, Presario 2107AP, Presario 2107EA, Presario 2108EA, Presario 2108US, Presario 2109EA, Presario 2110AP, Presario 2110CA, Presario 2110EA, Presario 2110LA, Presario 2110US, Presario 2111AP, Presario 2111EA, Presario 2112AP, Presario 2112EA, Presario 2113AP, Presario 2114AP, Presario 2114EA, Presario 2115AP, Presario 2115EA, Presario 2116AP, Presario 2117AP, Presario 2117EA, Presario 2118AD, Presario 2118EA, Presario 2119EA, Presario 2120AD, Presario 2120AP, Presario 2120EA, Presario 2120LA, Presario 2122AD, Presario 2123AD, Presario 2123AP, Presario 2124AD, Presario 2124AP, Presario 2125AC, Presario 2125AD, Presario 2125AP, Presario 2125EA, Presario 2126AC, Presario 2126AD, Presario 2126EA, Presario 2127AC, Presario 2127AD, Presario 2127EA, Presario 2128AC, Presario 2128AD, Presario 2128EA, Presario 2129AD, Presario 2129EA, Presario 2130AC, Presario 2130AD, Presario 2130AP, Presario 2130EA, Presario 2131AC, Presario 2131AD, Presario 2131EA, Presario 2132AC, Presario 2132RS, Presario 2133AC, Presario 2133AD, Presario 2133AP, Presario 2133EA, Presario 2134AD, Presario 2134EA, Presario 2135AC, Presario 2135AD, Presario 2135AP, Presario 2135CA, Presario 2135EA, Presario 2135US, Presario 2136AC, Presario 2136AD, Presario 2136EA, Presario 2136RSH, Presario 2137AC, Presario 2137AD, Presario 2137EA, Presario 2138AC, Presario 2138AD, Presario 2138EA, Presario 2139AC, Presario 2139AD, Presario 2140AC, Presario 2140AD, Presario 2140AP, Presario 2140CA, Presario 2140US, Presario 2141AC, Presario 2141AD, Presario 2141EA, Presario 2142EA, Presario 2143AD, Presario 2143AP, Presario 2144AD, Presario 2144EA, Presario 2145AD, Presario 2145AP, Presario 2145CA, Presario 2145EA, Presario 2145US, Presario 2146AD, Presario 2146EA, Presario 2147AD, Presario 2147EA, Presario 2148AD, Presario 2148EA, Presario 2149AD, Presario 2149EA, Presario 2150AP, Presario 2150US, Presario 2151AD, Presario 2151EA, Presario 2153AP, Presario 2154AP, Presario 2154EA, Presario 2155, Presario 2155EA, Presario 2155US, Presario 2156EA, Presario 2158EA, Presario 2160EA, Presario 2161EA, Presario 2161US, Presario 2162EA, Presario 2162US, Presario 2163EA, Presario 2164EA, Presario 2165EA, Presario 2166EA, Presario 2167EA, Presario 2169EA, Presario 2170US, Presario 2172EA, Presario 2173EA, Presario 2175EA, Presario 2175US, Presario 2176, Presario 2186RS, Presario 2188CL, Presario 2190US, Presario 2195, Presario 2195US, Presario 2199US, Presario 2500, Presario 2500 Series, Presario 2500AP, Presario 2500LA, Presario 2505AP, Presario 2510AP, Presario 2510EA, Presario 2510LA, Presario 2511EA, Presario 2512EA, Presario 2515AP, Presario 2515EA, Presario 2516EA, Presario 2520AP, Presario 2520EA, Presario 2521EA, Presario 2525AP,

Presario 2525CA, Presario 2525EA, Presario 2525US, Presario 2526EA, Presario 2528CL, Presario 2529CL, Presario 2530AP, Presario 2535AP, Presario 2535QV, Presario 2538CL, Presario 2540, Presario 2540AP, Presario 2545AP, Presario 2545US, Presario 2550AP, Presario 2555AP, Presario 2555US, Presario 2560AP, Presario 2565AP, Presario 2570US, Presario 2575US, Presario 2580US, Presario 2585US, Presario 2590US, Presario 2594US, Presario 2596US, Presario 2597US, Presario 2598US, Presario 2700, Presario 2700T, Presario 2700US, Presario 2701T, Presario 2702TW, Presario 2710US, Presario 2715US, Presario 2720US, Presario 700, Presario 700 series, Presario 700US, Presario 700Z, Presario 701, Presario 701CL, Presario 705, Presario 705US, Presario 710, Presario 711cl, Presario 715, Presario 720US, Presario 721CL, Presario 722US, Presario 723RSH, Presario 725, Presario 725US, Presario 730US, Presario 732US, Presario 800, Presario 800 series, Presario 800XL, Presario 80XL550, Prosignia 150. DELL: Inspiron 1000, Inspiron 1200, Inspiron 1300, Inspiron 2200, Inspiron 3000, Inspiron 3200, Inspiron 3500 Series, Inspiron 7000 Series, Inspiron B120, Inspiron B130, Latitude 110L, Latitude 120L. FUJITSU: Amilo A1640, Amilo D7830, Amilo M4100, Amilo M6100, Amilo M6300, Amilo M6500, Amilo M6800, Amilo M7800, Amilo M-7800, Amilo M8800, LifeBook A Series, LifeBook A1010, LifeBook A4170, LifeBook A4177, LifeBook A4178, LifeBook A4187, LifeBook A4190, LifeBook A6025, LifeBook C1010, LifeBook C1020, LifeBook C1320, LifeBook C1320D, LifeBook C1321, LifeBook C1321D, LifeBook C2110, LifeBook C2111, LifeBook C2210, LifeBook C2220, LifeBook C2230, LifeBook C4175, LifeBook C6175, LifeBook C6185, LifeBook C6597, LifeBook E2010, LifeBook E4010, LifeBook E4010D, LifeBook E7000 series, LifeBook E7010, LifeBook E7110, LifeBook N3500, LifeBook N3510, LifeBook N3511, LifeBook N3520, LifeBook N3530, LifeBook S7010, LifeBook S7010D, LifeBook S7020, LifeBook T4210, LifeBook T4215, LifeBook T4220. GATEWAY: 3018GZ, 3040GZ, 3520GZ, 3522GZ, 3525GB, 3545GZ, 3550GH, 3550GZ, 3610GZ, 400SD4, 4012GZ, 4024GZ, 4025GZ, 4026GZ, 4028GZ, 4028JP, 4030GZ, 450RGH, 450ROG, 450S, 450SX4, 450X, 4520GZ, 4525GZ, 4530GH, 4530GZ, 4535GX, 4535GZ, 4536GZ, 4538GZ, 4540GZ, 4541BZ, 4542GP, 4543BZ, 600YG2, 600YGR, 6010GZ, 6018GH, 6018GZ, 6020GZ, 6021GH, 6021GZ, 6022GZ, 6023GP, 6510GZ, 6518GZ, 6520GZ, 6525GP, 6531GZ, 6834MX, 7110GX, 7305GZ, 7324GZ, 7325GZ, 7326GZ, 7415GX, 8510GH, 8510GZ, 8515GZ, C120X, C-141X, CX200S, CX200X, CX210, CX210X, CX2608, CX2610, CX2615, CX2618, CX2619, CX2620, CX2720, CX2726, CX2728, E-100M, E-100M G, E-100M, SB, E-155C, E-155C G, E-265M, E-265M G, E-295, E-295C, E-475M, E-475M G, E525-2200, ID49C, ID49C07U,, M-1408J, M-1410J, M-1411J, M-1412, M-150S, M-150X, M-150XL, M-151, M-152, M-153, M-153S, M-153X, M-153XL, M-1615, M-1617, M-1618, M-1618N, M-1618R, M-1619J, M-1622, M-1622H, M-1624, M-1625, M-1626, M-1628, M-1629, M-1630J, M-1631J, M-1632J, M-1634U, M-2000, M210, M210S, M210X, M210XL, M-24, M-2400, M-2404U, M-2408J, M-2409J, M-2410J, M-2410U, M-2414U, M-2421U, M250, M250A, M250B, M250E, M250ES, M250G, M250GS, M255-E, M255-E, SB, M-2623U, M-2624U, M-2625U, M-2626U, M280, M280E, M285-E, M285-E, SB, M320, M320S, M320X, M320XL, M325, M360, M360A, M360B, M360C, M460B, M460QS, M465-E, M465-E, SB, M465-G, M-6205M, M-6206M, M-6207M, M-6305, M-6307, M-6308, M-6309, M-6312, M-6315, M-6316, M-6317, M-6318, M-6320, M-6322, M-6323, M-6324, M-6325, M-6332, M-6333, M-6334, M-6335, M-6337, M-6339U, M-6340U, M-6705, M-6750, M-6750H, M-6752, M-6755, M680, M-6801D, M-6801M, M-6801MT, M-6802M, M-6803M, M-6804M, M-6805M, M-6806M, M-6807M, M-6808M, M-6809M, M-6810M, M-6811M, M-6812M, M-6813M, M-6814M, M-6815, M-6816, M-6817, M-6821B, M-6822, M-6823, M-6823A, M-6824, M-6825J, M-6826J, M-6827, M-6827J, M-6828B, M-6829B, M-6834, M-6839J, M-6840J, M-6841, M-6842J, M-6843, M-6844, M-6846, M-6847, M-6848, M-6849, M685, M-6850FX, M-6851, M-6854M, M685E, M685-E, M685-E, SB, M-6862, M-6864FX, M-6866, M-6867, M-6873B, M-6873H, M-6874H, M-6875B, M-6876B, M-6877B, M-6878, M-6878H, M-6879J, M-6880, M-6881, M-7000, M-73, M-7301H, M-7301U, M-7309H, M-7315U, M-7317U, M-7325U, M-7328U, M-73305U, M-7332H, M-7333U, M-7334U, M-78, M-7810J, M-7818U, M-7844U, MC7801, MC7801U, MD2419U, MD2601U, MD2614U, MD7309U, MD7818U, MD7822U, ML3109, ML3706, ML6226b, ML6228, ML6228h, ML6232, ML6714, ML6720, ML6721, ML6725, ML6732, MP6954, MP8708, MP8709, MS2285, MT3418, MT3419, MT3421, MT3422, MT3423, MT3705, MT3707, MT3707b, MT6224j, MT6225j, MT6451, MT6452, MT6456, MT6457, MT6459, MT6704, MT6704h, MT6705, MT6706, MT6707, MT6708, MT6709, MT6709h, MT6711, MT6723, MT6728, MT6730, MT6821, MT6828, MT6828h,

MT6830, MT6831, MT6832b, MT6833b, MT6834b, MT6835j, MT6839b, MT6840, MT6841, MT6916, MT6920, MX1023, MX1023h, MX1025, MX1026, MX1027, MX3042, MX3044, MX3044h, MX3103b, MX3142m, MX3143m, MX3210, MX3212, MX3215, MX3228, MX3231, MX3410, MX3410h, MX3412, MX3412h, MX3414, MX3416, MX3417, MX3558, MX3558h, MX3560, MX3560h, MX3562, MX3563, MX3563h, MX3610, MX3701, MX3702, MX6025, MX6025h, MX6027, MX6027h, MX6028, MX6030, MX6121, MX6123, MX6124, MX6124h, MX6128, MX6131, MX6135, MX6211b, MX6214, MX6215b, MX6216, MX6420, MX6421, MX6422, MX6423, MX6424, MX6425, MX6426, MX6427, MX6428, MX6430, MX6431, MX6433, MX6436, MX6437, MX6438, MX6439, MX6440, MX6441, MX6442, MX6444, MX6444h, MX6445, MX6446, MX6447, MX6448, MX6450, MX6453, MX6454, MX6455, MX6625, MX6627, MX6627h, MX6629, MX6629h, MX6631, MX6633, MX6633h, MX6641, MX6650, MX6650h, MX6708, MX6708h, MX6710, MX6750, MX6912, MX6919, MX6920, MX6920h, MX6921b, MX6922b, MX6923b, MX6926b, MX6927, MX6928, MX6930, MX6931, MX6946m, MX6947m, MX6951, MX6955, MX6956, MX6957, MX6958, MX6959, MX6960, MX6961, MX6961h, MX7118, MX7122, MX7337, MX7337h, MX7515h, MX7520h, MX8520, MX8523, MX8525, MX8528, MX8554B, MX8556F, MX8710, MX8711, MX8715, MX8734, MX8736j, MX8738, MX8741, NV57H, NV57H13U, NV7316U, NV78, NV7802U, NX100X, NX200S, NX200X, NX250X, NX260X, NX270S, NX500S, NX500X, NX510, NX550X, NX550XL, NX560X, NX560XL, NX570, NX570S, NX570X, NX850X, NX850XL, NX860, NX860S, NX860X, NX860XL, P-170L, P-170X, P-171S, P-171S FX, P-171X, P-171XL, P-172S FX, P-172X, P-172XL FX, P-173XL, P-6301, P-6302, P-6311, P-6312, P-6313, P-6313H, P-6317, P-6318U, P-6822, P6825, S-7110M, S-7125C, S-7200C, S-7200N, S-7210M, S-7220M, S-7225C, S-7310M, S-7320M, S-7500N, S-7510N, S-7700N, S-7710M, S-7710N, SA1, Solo 1100, Solo 1150, Solo 1200, Solo 1400, Solo 1450, Solo 600YG2, Solo 600YGR, T-140X, T-1602M, T-1603M, T-1604M, T-1605M, T-1616, T-1620, T-1621, T-1622, T-1623, T-1625, T-1628, T-1628H, T-1629, T-1630, T-1631, T-6208C, T-6303C, T-6304C, T-6305C, T-6307C, T-6308C, T-6311, T-6313, T-6313H, T-6315C, T-6316C, T-6317C, T-6318C, T-6319C, T-6320C, T-6321, T-6322C, T-6324C, T-6325C, T-6326C, T-6327C, T-6330U, T-6801M, T-6815, T-6815h, T-6816h, T-6818C, T-6819C, T-6820C, T-6821C, T-6822C, T-6825C, T-6826C, T-6827C, T-6828, T-6829, T-6829H, T-6830C, T-6831C, T-6832C, T-6834C, T-6836, T-6840C, T-6841H, T-6842, T-6842H, W322, W340UI, W350A, W350i, W6501, W650i. HP:Business Notebook N1050V, Business Notebook NX9000, Business Notebook NX9005, Business Notebook NX9010, OmniBook 2100 series, OmniBook 2103, OmniBook 2104, OmniBook 2105, OmniBook 2106, OmniBook 2120, OmniBook 2121, OmniBook 2122, OmniBook 2123, OmniBook 2124, OmniBook 2125, OmniBook 2126, OmniBook 2127, OmniBook 3000, OmniBook 3000CTX, OmniBook 3100, OmniBook 3101, OmniBook 3102, OmniBook 3250, OmniBook 4100, OmniBook 4101, OmniBook 4102, OmniBook 4103, OmniBook 4104, OmniBook 4105, OmniBook 4106, OmniBook 4107, OmniBook 4108, OmniBook 4110, OmniBook 4111, OmniBook 4150, OmniBook 4150B, OmniBook 500, OmniBook 500B, OmniBook 6000 series, OmniBook 6000B, OmniBook 6000C, OmniBook 6100, OmniBook 7000, OmniBook 7100, OmniBook 7103T, OmniBook 7150, OmniBook 900, OmniBook XE, OmniBook XE 4100, OmniBook XE 4400, OmniBook XE 4500, OmniBook XE2, OmniBook XE2-DA, OmniBook XE2-DB, OmniBook XE2-DC, OmniBook XE2-DD, OmniBook XE2-DE, OmniBook XE2-DI, OmniBook XE3, OmniBook XE3L, OmniBook XE-DA, OmniBook XT1000, OmniBook XT6200, Pavilion 6000, Pavilion N3000, Pavilion N3100, Pavilion N3110, Pavilion N3150, Pavilion N3190, Pavilion N3210, Pavilion N3215, Pavilion N3250, Pavilion N3270, Pavilion N3290, Pavilion N3295, Pavilion N3310, Pavilion N3330, Pavilion N3350, Pavilion N3370, Pavilion N3390, Pavilion N3400, Pavilion N3402, Pavilion N3410, Pavilion N3438, Pavilion N3478, Pavilion N3490, Pavilion N5000, Pavilion N5100, Pavilion N5125, Pavilion N5130, Pavilion N5150, Pavilion N5170, Pavilion N5190, Pavilion N5195, Pavilion N5200, Pavilion N5210, Pavilion N5210M, Pavilion N5240, Pavilion N5250, Pavilion N5270, Pavilion N5290, Pavilion N5295, Pavilion N5300, Pavilion N5310, Pavilion N5340, Pavilion N5350, Pavilion N5390, Pavilion N5400, Pavilion N5415, Pavilion N5420L, Pavilion N5421L, Pavilion N5425, Pavilion N5430, Pavilion N5435, Pavilion N5440, Pavilion N5441, Pavilion N5445, Pavilion N5450, Pavilion N5451, Pavilion N5455, Pavilion N5470, Pavilion N5474, Pavilion N5475, Pavilion N5490, Pavilion N5491, Pavilion N5495, Pavilion N5500, Pavilion N5511L, Pavilion N5584, Pavilion N6000, Pavilion N6100, Pavilion N6195, Pavilion XF Series, Pavilion XF145, Pavilion XF255, Pavilion XF328, Pavilion XF335, Pavilion XH Series, Pavilion XH156, Pavilion

XH176, Pavilion XH215, Pavilion XH226, Pavilion XH260, Pavilion XH35, Pavilion XH365, Pavilion XH395, Pavilion XH455, Pavilion XH485, Pavilion XH555, Pavilion XH675, Pavilion XT Series, Pavilion XT1135, Pavilion XT118, Pavilion XT155, Pavilion XT236, Pavilion XT276, Pavilion XT375, Pavilion XT412, Pavilion XT4345QV, Pavilion XT5300, Pavilion XT5366WM, Pavilion XT537QV, Pavilion XT545, Pavilion XT5477WM, Pavilion XT595, Pavilion XZ Series, Pavilion XZ168, Pavilion XZ185, Pavilion XZ275, Pavilion XZ295, Pavilion XZ355, Pavilion ZE1000 series, Pavilion ZE1110, Pavilion ZE1115, Pavilion ZE1210, Pavilion ZE1220, Pavilion ZE1230, Pavilion ZE1250, Pavilion ZE4000, Pavilion ZE4100, Pavilion ZE4100, Pavilion ZE4115, Pavilion ZE4125, Pavilion ZE4145, Pavilion ZE4200, Pavilion ZE4210, Pavilion ZE4220, Pavilion ZE4230, Pavilion ZE4236, Pavilion ZE4239, Pavilion ZE4240, Pavilion ZE4300, Pavilion ZE4300, Pavilion ZE4315CA, Pavilion ZE4315US, Pavilion ZE4325CA, Pavilion ZE4325US, Pavilion ZE4335US, Pavilion ZE4365US, Pavilion ZE4400 Series, Pavilion ZE4401, Pavilion ZE4402, Pavilion ZE4420, Pavilion ZE4427, Pavilion ZE4430, Pavilion ZE4455EA, Pavilion ZE4500, Pavilion ZE4510, Pavilion ZE4530US, Pavilion ZE4540US, Pavilion ZE4547, Pavilion ZE4560US, Pavilion ZE4610US, Pavilion ZE4630US, Pavilion ZE4805US, Pavilion ZE5000 series, Pavilion ZE5155, Pavilion ZE5165, Pavilion ZE5170, Pavilion ZE5185, Pavilion ZE5200, Pavilion ZE5279, Pavilion ZE5300, Pavilion ZE5366, Pavilion ZE5375US, Pavilion ZE5385US, Pavilion ZE5395US, Pavilion ZE5470US, Pavilion ZE5475CA, Pavilion ZE5475F, Pavilion ZE5478CL, Pavilion ZE5490US, Pavilion ZE5560, Pavilion ZE5570US, Pavilion ZE5580US, Pavilion ZE5602, Pavilion ZE5604RS, Pavilion ZE5607WM, Pavilion ZE5615SR, Pavilion ZE5620US, Pavilion ZE5630US, Pavilion ZE5700, Pavilion ZE5715CA, Pavilion ZE5720US, Pavilion ZE5730US, Pavilion ZE5738RS, Pavilion ZT Series, Pavilion ZT1000, Pavilion ZT1114, Pavilion ZT1121s, Pavilion ZT1125, Pavilion ZT1130, Pavilion ZT1131s, Pavilion ZT1135, Pavilion ZT1141, Pavilion ZT1145, Pavilion ZT1150, Pavilion ZT1151, Pavilion ZT1152, Pavilion ZT1155, Pavilion ZT1161, Pavilion ZT1162, Pavilion ZT1170, Pavilion ZT1171, Pavilion ZT1175, Pavilion ZT1180, Pavilion ZT1185, Pavilion ZT1190, Pavilion ZT1195, Pavilion ZT1200, Pavilion ZT1201, Pavilion ZT1230, Pavilion ZT1250, Pavilion ZT1260, Pavilion ZT1270, Pavilion ZT1290. LENOVO: 29589PU, 2958-9PU, 3000 G400, 3000 G400 14001, 3000 G400 2048, 3000 G410 series, 3000 G410 2049, 3000 G430, 3000 G430 4152, 3000 G430 4153, 3000 G430A, 3000 G430L, 3000 G430M, 3000 G450, 3000 G450 2949, 3000 G450A, 3000 G450M, 3000 G510, 3000 G530, 3000 G530 4151, 3000 G530A, 3000 G530M, 3000 N500, 3000 Y400, 3000 Y400 9454, 3000 Y410 series, 3000 Y410 7757, 3000 Y410a, 3000 Y410a 7757, 3000 Y500, 3000 Y500 7761, 3000 Y510, 3000 Y510 7758, 3000 Y510a series, Essential G555, G550, G550 29589PU, G550 2958-9PU, IdeaPad 29589PU, IdeaPad 2958-9PU, IdeaPad B560, IdeaPad B560-433028U, IdeaPad B570, IdeaPad G430, IdeaPad G430 20003, IdeaPad G460, IdeaPad G460 0677, IdeaPad G460 20041, IdeaPad G530, IdeaPad G550 29589PU, IdeaPad G550 2958-9PU, IdeaPad G560, IdeaPad G560 0679, IdeaPad U150, IdeaPad U150 SFO, IdeaPad U150 STW, IdeaPad U150-690968U, IdeaPad U150-6909H9J, IdeaPad U150-6909HAJ, IdeaPad U150-6909HFJ, IdeaPad U150-6909HGJ, IdeaPad U330, IdeaPad U330 20001, IdeaPad U330 2267, IdeaPad U330A, IdeaPad U450P, IdeaPad U450P 20031, IdeaPad U450P 3389, IdeaPad V350, IdeaPad V430a, IdeaPad V450a, IdeaPad V560, IdeaPad V560-43422GU, IdeaPad V570, IdeaPad Y310, IdeaPad Y330, IdeaPad Y330A, IdeaPad Y330G, IdeaPad Y410, IdeaPad Y430 series, IdeaPad Y430 20005, IdeaPad Y430 2781, IdeaPad Y430a, IdeaPad Y430g, IdeaPad Y510 series, IdeaPad Y510 7758, IdeaPad Y530 series, IdeaPad Y530 20009, IdeaPad Y530 4051, IdeaPad Y530a, IdeaPad Y550, IdeaPad Y550 4186, IdeaPad Y550A, IdeaPad Y550P, IdeaPad Y550P 3241, IdeaPad Y560, IdeaPad Y710 series, IdeaPad Y710 4054, IdeaPad Y730 series, IdeaPad Y730 4053, IdeaPad Y730a, IdeaPad Z565, IdeaPad Z565-43113LU. TOSHIBA: Satellite 1000, Satellite 1000-S157, Satellite 1000-S158, Satellite 1000-Z2, Satellite 1005, Satellite 1005-S157, Satellite 1005-S158, Satellite 1100, Satellite 1200 series, Satellite 1200-S121, Satellite 1200-S122, Satellite 1200-S252, Satellite 1600 series, Satellite 1605CDS, Satellite 1620CDS, Satellite 1625CDT, Satellite 1640CDT, Satellite 1670CDS, Satellite 1675CDS, Satellite 1690CDT, Satellite 1695CDT, Satellite 1700 series, Satellite 1715XCDS, Satellite 1730, Satellite 1730CDT, Satellite 1735XCDS, Satellite 1750, Satellite 1755, Satellite 1755CDT, Satellite 1755CE, Satellite 1755DVD, Satellite 3000 series, Satellite 3000-S304, Satellite 3000-S307, Satellite 3000-S309, Satellite 3000-S353, Satellite 3000-S514, Satellite 3005-S303, Satellite 3005-S304, Satellite 3005-S307, Satellite 3005-S308, Satellite 3005-

S309, Satellite 3005-S403, Satellite 3005-S504, Satellite A100-S2211TD, Satellite A100-ST3211, Satellite A105-S101, Satellite A105-S1013, Satellite A105-S1014, Satellite A105-S171, Satellite A105-S1711, Satellite A105-S1712, Satellite A105-S2001, Satellite A105-S2011, Satellite A105-S2021, Satellite A105-S2031, Satellite A105-S2041, Satellite A105-S2051, Satellite A105-S2061, Satellite A105-S2071, Satellite A105-S2081, Satellite A105-S2091, Satellite A105-S2101, Satellite A105-S2111, Satellite A105-S2121, Satellite A105-S2131, Satellite A105-S2141, Satellite A105-S215TD, Satellite A105-S2194, Satellite A105-S2231, Satellite A105-S2236, Satellite A105-S2712, Satellite A105-S2713, Satellite A105-S2716, Satellite A105-S2717, Satellite A105-S2719, Satellite A105-S361, Satellite A105-S3611, Satellite A110-S1111, Satellite A80, Satellite A80-S178TD, Satellite A85 series, Satellite A85-S107, Satellite A85-S1071, Satellite A85-S1072, Satellite E205-S1904, Satellite L10, Satellite L15-S104, Satellite L15-S1041, Satellite L20, Satellite L20-S310TD, Satellite L25, Satellite L25-S119, Satellite L25-S1192, Satellite L25-S1193, Satellite L25-S1194, Satellite L25-S1195, Satellite L25-S1196, Satellite L25-S121, Satellite L25-S1215, Satellite L25-S1216, Satellite L25-S1217, Satellite L35-S1054, Satellite L35-S2151, Satellite L35-S2161, Satellite L35-S2171, Satellite L35-S2174, Satellite L35-S2194, Satellite L35-S2316, Satellite L35-S2366, Satellite L45-S7409, Satellite L45-S7419, Satellite L45-S7423, Satellite L45-S7424, Satellite L45-SP2066, Satellite M105-S1011, Satellite M105-S1021, Satellite M105-S1031, Satellite M105-S1041, Satellite M115-S1061, Satellite M115-S1064, Satellite M115-S1071, Satellite M115-S1074, Satellite M115-S3104, Satellite M30X series, Satellite M30X-1592ST, Satellite M30X-1593ST, Satellite M30X-S171ST, Satellite M30X-S181ST, Satellite M30X-S191TD, Satellite M30X-S221ST, Satellite M30X-S221TD, Satellite M35X series, Satellite M35X-S109, Satellite M35X-S111, Satellite M35X-S114, Satellite M35X-S1141, Satellite M35X-S1142, Satellite M35X-S1143, Satellite M35X-S149, Satellite M35X-S1491, Satellite M35X-S1492, Satellite M35X-S161, Satellite M35X-S1611, Satellite M35X-S163, Satellite M35X-S1631, Satellite M35X-S309, Satellite M35X-S3091, Satellite M35X-S311, Satellite M35X-S3111, Satellite M35X-S3112, Satellite M35X-S329, Satellite M35X-S3291, Satellite M35X-S349, Satellite M35X-S3491, Satellite M40-S312TD, Satellite M45-S165, Satellite M45-S169, Satellite M45-S1691, Satellite M55-S1001, Satellite M55-S139, Satellite M55-S1391, Satellite M60 series, Satellite M60-S6111TD, Satellite M60-S8112ST, Satellite M60-S8112TD, Satellite M60-S811ST, Satellite M60-S811TD, Satellite M65-S809, Satellite M65-S8091, Satellite M65-S8092, Satellite M65-S821, Satellite M65-S8211, Satellite M65-S8213, Satellite M65-S9062, Satellite M65-S9063, Satellite M65-S9064, Satellite M65-S9065, Satellite M65-S909, Satellite M65-S9091, Satellite M65-S9092, Satellite M65-S9093, Satellite T135D-S1324, Satellite T135-S1309, Satellite U300-ST3091, Satellite U300-ST3092, Satellite U305-S5077, Satellite U305-S5087, Satellite U305-S5097, Satellite U305-S5107, Satellite U305-S5117, Satellite U305-S5127, Satellite U305-S7448, Satellite U305-S7467, Satellite U305-S7477, Tecra L2-S011, Tecra M8-8011X, Tecra M8-S8011, Tecra M8-ST3093, Tecra M8-ST3094.

PESO .250 kg

ALTO 9.6 cm

LARGO 4.3 cm

ANCHO 3.1 cm